




Installation and Operating Instructions for

NORTHSTAR

Electric Ranges (Model 1954)
Gas/Electric Combos (Model 1955)
Gas Ranges (Model 1956)



Thank you for purchasing a Northstar Retro Range.
You have purchased a quality, world-class product.
Years of engineering experience have gone into its manufacturing.
To ensure that you will enjoy many years of trouble-free
operation, we have developed this User Guide.
It is full of valuable information on how to operate and maintain
your range properly and safely. Please read it carefully.

**Elmira
Stove
Works**

GAS RANGE WARNING

WARNING: If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

– Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

– **WHAT TO DO IF YOU SMELL GAS.**

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

BEFORE USING YOUR RANGE READ THIS BOOK CAREFULLY

If you received a damaged range:

Immediately contact the dealer that sold you the range.

Before you request service:

Check Troubleshooting. It lists causes of minor operating problems that you may be able to correct yourself.

TABLE OF CONTENTS

SAFETY INSTRUCTIONS – All Models.....	3	MAINTENANCE & MINOR REPAIRS.....	16
AMPERAGE REQUIREMENTS – BTU's.....	4	Removing Oven Door.....	16
SAFETY INSTRUCTIONS – Gas	4	Lubrication & Minor Service	16
INSTALLING YOUR RANGE	5	WARMING DRAWER OPTION	17
INSTALLATION OF RANGE INTO CABINETS	6	Removal of Storage Drawer	17
INSTALLING YOUR EXHAUST HOOD.....	6	COOKING TIPS.....	18
SMOOTH TOP ELECTRIC COOKTOP	7	Convection Cooking Tips.....	18
SELECTION OF POTS & PANS		Broiling.....	18
FOR ELECTRIC TOP.....	7	Convection Broiling	18
GRIDDLE – Optional.....	9	General Broiling Tips.....	19
GAS COOKTOP.....	9	Convection Roasting Rack	19
GAS BURNER CLEANING	10	Air Circulation.....	19
GAS ADJUSTING FOR PROPER FLAME	10 & 14	Oven Rack Positions.....	19
OVEN VENT - GAS.....	11	Rack Placement for Specific Foods.....	20
GAS SUPPLY SYSTEM	11	Using Aluminum Foil in the Oven	20
GAS RANGE CONVERSION TO LP.....	12-13	ROASTING CHART.....	21
OVEN CONTROL – CLOCK.....	14	BAKING CHART	22
Setting the Clock	14	BROILING CHART.....	22
Using the Minute Timer	14	CONVECTION COOKING	23-25
Bake & Broil Preheating Oven.....	15	WIRING DIAGRAM	27
Automatic Timed Bake.....	15	CLEANING GUIDE.....	28
Delayed Bake.....	15	TROUBLESHOOTING	29
Broil and Vari-Broil.....	15	SERVICE	Back Cover
Self Cleaning Oven.....	15 & 16	WARRANTY	Back Cover

SAFETY INSTRUCTIONS

(All Models)

IMPORTANT! Save these instructions for the local inspector's use.

WARNING! Prior to installing this appliance, read the Safety Instructions as they relate to Installation on pages 4 through 6 of this manual. Failure to follow these instructions could result in serious electric hazard, risk of fire, and/or personal injury.

Models 1954 and 1955 are equipped with a 240 volt, standard range power cord & plug. See page 4 for amp ratings of each model.

Models 1956 comes with a 120 volt, 10 amp power cord & plug.

Use this appliance for its intended use, as described in this manual.

Never use your appliance for warming or heating the room.

Do not assume that you know how to operate all parts of the range. Some features may work differently from those of your previous range.

Do not climb, stand or hang on the door or range top. This can damage the range or tip it over, causing severe personal injury.

Children

Do not leave children alone in the area where your range is in use. They should never be allowed to stand or sit on any part of this appliance.

Instruct your small children that the range is not a toy and could hurt them. As your children grow up, teach them the proper and safe use of the range.

Children must be taught not to use the oven door as a stepping stool to reach the cabinet above, as it may result in an injury.

Caution

Do not store items of interest to children on console above the range or on the back of the cooking surface. Children climbing to reach items could be seriously injured.

When cleaning cycle is on, the oven door and cooking surface will be hot. Keep children away from the range as a safety precaution.

Storage

Do not store gasoline, flammable vapors or materials, etc., in the oven, storage drawer, warmer or around the appliance area.

Hot Surface

Exercise caution. Surfaces may be hot enough to burn. Electric elements may be hot even when they appear dark in color.

Do not operate surface burners without utensils in place.

Allow elements and burner surfaces to cool before cleaning. If a wet sponge or cloth is used to wipe spills on a hot cooking area, be careful to avoid steam burn. Some cleaners can produce noxious fumes if applied to a hot surface.

Loose clothing of flammable material (pot holders) could ignite if brought in contact with hot burners and may cause severe burns.

Moist or damp pot holders on hot surfaces may result in burns from steam. Do not let pot holders touch hot heating elements. Do not use towels or other bulky cloths as pot holders.

Cooktop temperatures increase with the number of elements on. With three or four elements turned on, surface temperatures are high. Exercise care when touching the cooktop.

Fire (Optional Exhaust Hood)

Keep the hood and grease filters clean to maintain good venting and to avoid grease fires.

Do not let cooking grease or other flammable materials accumulate in or near the range.

Grease

Grease is flammable and should be handled carefully. Avoid letting grease deposits collect around the range in vent fans. Don't leave cans of drippings sit around the range; refrigerate or dispose of promptly. Let quantities of hot fat (a pan of deep fat for example) cool before attempting to move or handle it. Grease fires can often be extinguished by quickly putting on the pan lid or by covering with baking soda. **Do not attempt to extinguish with water** because this will spread the fire.

Never pick up a flaming pan.

Oven

Stand away from range when opening the oven door. Hot air or steam which escapes can cause burns.

Do not heat unopened food containers in the oven. Pressure could build up and the container could burst, causing injury or damage to the range.

Keep oven vent ducts unobstructed.

Keep oven free from grease build up.

Place oven rack in desired position while oven is cool. If rack must be handled when hot, do not let pot holder touch heating elements in the oven.

Pull out oven rack to the rack stop to reduce chance of burns from touching hot surfaces of the door and oven.

When using cooking or roasting bags in oven, follow the manufacturer's directions.

Do not use your oven to dry newspapers.

Aluminum Foil

Do not use aluminum foil to cover oven racks. This will restrict heat circulation.

Plastics

All plastics are vulnerable to heat, although some will withstand higher temperatures than others. Keep all plastics away from parts of the range which may become slightly more than warm when the range is in operation.

Self-Cleaning Oven

The door gasket is essential for a good seal. Care should be taken not to rub, damage or move the gasket.

Do not use oven cleaners on self-cleaning ovens prior to cleaning. Damage may occur to oven finish at high temperatures. Remove aluminum or plastic utensils, food or combustible materials from oven and cooktop before self-cleaning. (See *Self-Cleaning – Page 15*)

NOTE: Oven cleaner will not harm porcelain oven but should not be used in conjunction with selfcleaning.

Surface Cooking

Use proper pan size. Select pans large enough to cover the element. The use of undersized pans will expose a portion of the element which may result in burns, ignition of clothing or spillovers directly on element.

Never leave surface units unattended at high heat setting. Boil over or boil dry conditions could result in a fire.

Do not use glass or glazed ceramic cookware on the surface burners, as sudden change in temperature may break them.

Always turn off surface unit, before removing pots or pans.

Turn handle of the pan toward the center of the cooktop, without extending over nearby elements. This will reduce the possibility of accidentally overturning the pan.

Let hot pans cool in a safe place, out of the reach of young children. Never set hot pots on a combustible surface.

Do not use decorative metal covers on electric surface elements. A covered element, when turned on, could result in a burn or damage to the element.

Frying

Use as little oil as possible. Filling the pan too full of oil can cause spillovers when food is added.

Foods for frying should be as dry as possible. Frost on frozen foods or moisture on fresh foods can cause hot oil to bubble up. Spillovers, fire and burns from splatters could occur.

Use a deep fat thermometer whenever possible to prevent overheating oil beyond smoking point.

Deep Fryer

Use extreme caution when moving a hot grease kettle or disposing of hot grease.

Ventilating Hoods

Clean ventilation hood frequently — grease should not be allowed to accumulate on hood or filter. When flaming foods under the hood, turn the fan off. The fan, when operating, may spread flame.

Service

Do not repair or service any part of the range unless specifically recommended in this manual. All other servicing should be referred to a qualified technician. Disconnect the range from wall receptacle, fuse, or breaker before performing service.

Safety

Your range, like many other household items, is heavy and can settle into soft floor coverings such as cushion vinyl or carpeting. When moving the range on this type of flooring use care.

If your range must stand beside a refrigerator, allow at least 2" between the two appliances for air circulation. The heat from the range may affect refrigerator performance.

Make sure that all the packing materials have been removed and that all controls are in the off position before plugging in the power cord.

Electrical Connection

Amperage requirements	BTU's NAT	BTU's LP
Model 1954- 40 Amps, 240 Volts	—	—
1955- 25 Amps, 240 Volts	43,000	38,700
1956- 10 Amps, 110 Volts	58,000	52,200

All ranges come with standard 4 wire range cord attached. This cord must be plugged into a standard range receptacle provided by your electrician.

SAFETY INSTRUCTIONS – GAS

Important Instructions

Do not use range as a heater. Never use the range as a kitchen heater. Prolonged use of the range without adequate ventilation can be hazardous. Oven controls and top burners are not designed for home heating and component failures that may result from such abuse are definitely not covered by the warranty.

WARNING: *This product must be installed by a licensed plumber or gas fitter, when installed within the Commonwealth of Massachusetts. Massachusetts approval code #G1-1202-18.*

#1 This installation must conform with local codes and ordinances. In the absence of local codes, installations must conform with American National Standard, National Fuel Gas Code ANSI Z223.1—latest edition (***) or CAN/CGA-B149—latest edition (***) installation codes.

#2 Input ratings shown on the serial/rating plate are for elevations up to 2,000 feet (609.6 m). For elevations above 2,000 feet (609.6 m), ratings are reduced at a rate of 4% for each 1,000 feet (304.8 cm) above sea level.

Mobile Home Installation

The installation of this range must conform to the Manufactured Home Construction and Safety Standards, Title 24 CFR, Part 3280 (formerly the Federal Standard for Mobile Home Construction and Safety, Title 24, HUD, Part 280); or when such standard is not applicable, the Standard for Manufactured Homes Installations 1982 (Manufactured Home Sites, Communities and Setups), ANSI A225.1q/NFPA 501A* or with local codes.

The installation of this range must conform with the current standards CAN/CSA-Z240–latest edition*** or with local codes. When this range is installed in a mobile home, it must be secured to the floor during transit. Any method of securing the range is adequate as long as it conforms to the standards listed above.

Note: The metal chassis of the range MUST be earth-grounded in order for the control panel and burner spark ignition to work. Check with a qualified electrician if you are in doubt as to whether the metal chassis of range is earth-grounded.

Copies of the standards listed may be obtained from:

* National Fire Protection Association
Batterymarch Park
Quincy, Massachusetts 02269

** American Gas Association
1515 Wilson Boulevard
Arlington, Virginia 22209

*** Canadian Standard Association
178 Rexdale Boulevard
Rexdale (Toronto), Ontario M9W 1R3

Floor Covering

Never install a range over inferior kitchen carpeting, vinyl tile or linoleum. These should be able to withstand at least 175°F without shrinking, warping or discoloring.

Curtains

If your range is near a window, use an appropriate window treatment. Do not use long curtains which could blow over the top burners and create a fire hazard.

If You Smell Gas

If this is a new range installation, your installer has not done a proper job of checking for leaks. Connections can loosen in transportation. If the range connections are not perfectly tight, you can have a small leak and therefore a faint gas smell.

FINDING A GAS LEAK IS USUALLY NOT A “DO IT YOURSELF” PROCEDURE.

Some leaks can only be found with the controls in the “on” position exposing the user to serious burns. Never use a match or flame to locate a leak. **Turn off the gas to the range and call a qualified serviceman.**

Flame Size: Top burner flame size should be adjusted so it does not extend beyond the edge of the cooking utensil. Excessive flame is hazardous.

Use of High Flame: When using a high flame, never leave any pans unattended on this heat setting for long periods. Hot oil is particularly hazardous since it can become hot enough to ignite.

Do not obstruct the flow of combustion and ventilation air to the range.

Any openings in the wall, behind the range or the floor under the range must be sealed.

Venting

Never block the vents (air openings of the range). They provide the air inlet and outlet which is necessary for the range to operate properly with correct combustion. The oven vent is located at the rear of the main top.

Type of Gas

Natural and LP Gas (propane). Ranges are factory assembled for natural gas unless otherwise specified and cannot be used with LP Gas without some adjustments. Be sure your range is correctly adjusted by a qualified serviceman or installer for the type of gas on which it is to be used. (See Conversion, page 12).

NOTE: In this manual, propane is referred to as LP (liquid petroleum).

Gas hook up locations - Model 1955: The 1/2” steel gas elbow exits the stove on the right side, 34” off the floor. On Model 1956, the connection is located in the center, 2” off the floor.

INSTALLING YOUR RANGE

Be sure your appliance is properly installed and grounded by a qualified technician in accordance with the installation instructions and local building codes.

Power cord installation

The new U.S. revised electrical code states that all new construction must use a FOUR WIRE range power cord. Existing construction may use a three wire range power cord. *NOTE: The difference is, a four wire cord has a separate ground. A three wire cord is grounded through the neutral.*

Installation, adjustment and service of this range must be performed only by a qualified gas range installer or electrical serviceman. This is necessary to insure proper operation of the range and to avoid the possibility of damage to the range or injury to the users.

WARNING: *Be careful when reaching into storage cabinets above range while it is in operation. One might accidentally contact a hot burner when using a hand for support or have one’s clothing come in contact with top burner flame.*

Location

If possible, the range should be located to avoid the main “traffic path” through the kitchen or where an open door might block a passageway or create an awkward working situation. If possible, it should be so located where cabinet working space is available on either side. Drafty locations should be avoided to prevent gas burner outage and poor air circulation.

Temperatures

To cook, you must have heat. Some parts of the range are therefore going to get warm or even hot. Consider this in choosing a range location. Do not leave children alone or unattended near the range when it is in use. Let burner grids and other surfaces cool before touching them or leaving them where children can reach them.

Clearances


This range may be installed with adjacent surfaces touching the base cabinets and the back flush with the back wall. Models 1955 and 1956 gas ranges require a CGA/AGA approved stainless steel gas flex line or a flexible copper coil 1/2” in diameter and at least three feet long so the range can be moved for service.

To eliminate the risk of burns or fire by reaching over heated surface burners, cabinet storage above the range should be avoided. If overhead storage is unavoidable, clearances between the cooking surface and unprotected wood or metal overhead cabinets must be no less than 32”. The clearances on electric models between the cooktop and unprotected overhead cupboards is 30”. This distance may be reduced to 24” when the bottom wood or metal cabinets are protected by not less than 1/4” thick flame retarding millboard covered with not less than No. 28MSG sheet steel, 0.015” thick stainless steel, 0.024” thick aluminum or 0.020” thick copper.

NOTE: Clearances specified to combustible construction (walls and materials) are based on a temperature rise of wood resulting from appliance operation. These clearances are suitable for walls of studding, lath and plaster or other types of combustible material which have a density of 20 lbs. per cu. ft. or more. No evaluation of clearances has been made for low density cellulose, fibre board and similar materials which have a density of less than 20 lbs. per cu. ft., nor to plastic tiles or sheeting.

The maximum depth of upper cabinets installed above the range is 13”.

See the **Minimum Clearances Chart** for electric and gas models below.



Minimum Clearances to Combustibles

	A	B	C	D	E	F
All Model Electric 1954	0”	0”	30”	0”	0”	13” max.
Combo Model 1954	3” min. ht. 18”	3” min. ht. 18”	32”	0”	0”	13” max.
All Gas Model 1956	3” min. ht. 18”	3” min. ht. 18”	32”	0”	0”	13” max.

1 = End of section of overhead cabinet

2 = Overhead center cabinet

3 = End wall or divider

Exhaust Hood Dimensions – 30” W x 22” D x 6” H

Hood should be installed 28” to 30” from the bottom of hood to the range cook top. See Full Installation information in Exhaust Hood Manual.


It is the responsibility of the installer to comply with the installation clearances specified in this manual.

Cabinet Openings

This range will fit into a 30 1/4” cabinet opening.

Leveling Your Range


Place rack in oven. Place level on rack, first side to side, then front to back.



If the range is not level, adjust leveling legs up or down with pliers or your fingers until range is level.

NOTE: Oven must be level for satisfactory baking performance.

ELECTRIC COOKTOP



Surface Elements Controls

Control knobs must be pushed in before turning them to a setting. They can be set anywhere between MAX and MIN.

The controls for the surface elements provide infinite heat settings. The numbers on the dial

serve as a reference. The control can be turned to any setting to provide the exact heat required.

NOTE: The “Push to Turn Safety Control Knobs” on the range are designed for child safety and to prevent accidental operation.

Before using your glass cooktop for the first time: turn the elements on MAX without a pan for 5 to 8 minutes or until smoking stops. This smoking is normal and non toxic.

High Speed Radiant - Electric Top Burners

Consists of a set of special RADIANT HEATER coils embedded in thermal insulation. The element is designed for fast heat response. You can see it light up almost immediately.

Each element is fitted with a thermal limiter to ensure the ceramic glass does not exceed the maximum SAFE operating temperature. You may notice the element going on and off a number of times during use. This is a normal occurrence.

To maximize the efficiency of this type of element we suggest you use it similarly to your previous burner. Turn to maximum until the desired temperature is reached, then turn it down to the setting that best maintains the desired heat.

- H or 9 – To start foods cooking and to bring foods to a boil.
- 8-7 – To hold a rapid boil.
- 6-5 – To fry foods.
- 4 – To cook large amounts of vegetables
- 3-2 – To keep food cooking after starting it on a lower setting.
- L – To keep foods warm until ready to serve.

Hot Lights

Hot lights are provided in the glass of all smooth top ranges. Light glows when a burner becomes hot and shuts off when the burner has cooled.

Controls

The radiant heating elements are controlled by a commonly used Infinite Heat Switch that works on the principle of percent on, percent off. For example, when the switch is turned to the medium setting, the element will be on only 50% of the time. Because of the fast heat-up with these types of elements, you will notice the units switching on and off.

Cookware

The best cooking results and the most economical use of electricity will be achieved by using smooth, flat-bottom pans. Pans should be at least the same size or slightly larger than the cooking area. Ceramic cookware suitable for stovetop cooking may be used. If pans smaller than the size of the heating element are used, care should be taken as the handles may get hot.

Built into each element, is a safety device which protects the element from overheating. If using pans which are not ideal, for example concave or convex bottom pans with shiny bases, or those with ridged or grooved bottoms, the thermal limiter can cause the element to switch off and on during cooking, which means that food will take longer to cook.

Very thin, badly dented, and distorted pans with uneven bottoms should not be used.

Pans with very shiny or reflective bottoms should not be used.

Never place utensils with a skirt (e.g. a wok) on the heated area.

Pans should not have rough bottoms. Do not slide pots on the ceramic glass cooking surface, as this may mark or scratch the cooktop.

If pans with aluminum bottoms are slid across the cooking surface, metal marks could result. Such marks are easily cleaned with any non-abrasive stainless steel cleaner, provided they are removed immediately and not allowed to bake onto the surface.

Any guidelines or recommendations given by the saucepan or cooking utensil manufacturer should be followed.

SELECTION & USE OF POTS & PANS

Flat Bottoms

Thick, flat bottoms absorb and distribute the heat from the element more evenly. Thin, uneven bottoms waste energy and create hot spots that may burn the food onto cookware.

Glass cooktops require heavy gauge flat bottom pans for best cooking results.

Check flatness with a ruler or straight edge. See figure 7.




Figure 7

Pot Diameter

Select element to match pan diameter. The pot should be slightly larger than the element to obtain best energy usage, and avoid spillovers flowing directly onto element.

Do not use pans extending more than one inch beyond element, except while canning. See figure 8.




Figure 8

Small diameter pans waste energy and spillage can flow onto element. This increases chance of fire and burns.

Use non-stick coated cookware, for easier clean up. Glass or pyroceram pans should be used only as the manufacturer describes.

Pressure cookers, deep fat fryers, canners, etc. must be of the correct size and have flat bottoms to work properly.

Energy Tips

Use cookware with tight-fitting lids, and flat bottoms which completely cover the heated portion of the element. Watch foods when bringing them to cooking temperatures at high heat. When food reaches cooking temperature, reduce heat to lowest setting that will keep it cooking.

Use residual heat with surface cooking. For example, when cooking eggs in the shell, bring water to a boil, then turn element off, and allow heat in water to complete cooking.

When boiling water for tea or coffee, heat only the amount needed. Do not use a wire trivet or any other kind of heat retarding pad between the pan and the element.

Things Not To Do On A Ceramic Cooktop

- Do not leave pots unattended or elements ON for extended periods of time. If an element is mistakenly left on for an extended period of time the built in thermal limiter will ensure that the heat build-up is insufficient to cause any adverse effects.
- Do not cook directly on the ceramic cooktop. The surface of the cooktop can be damaged, and will be more difficult to clean.
- Do not use wire trivets mats or aluminum foil. They offer no cooking advantages and can damage the ceramic glass surface. Never place plastic or any other material which might melt on any part of the cooktop.
- Do not use the cooktop as a chopping board or cutting surface. This type of use can scratch the surface.
- Do not leave heavy spills during cooking. Turn heat off and allow surface to cool down. Remove the spills with a clean, damp cloth (no detergent), taking care to avoid burning fingers. If there is detergent in the cloth, you may leave a layer of soil-laden film on the cooktop surface, which can result in discoloration next time the element is switched "on". If a detergent film builds up, use a ceramic glass cleaner-conditioner.

Care and Cleaning

To keep the exterior chrome trim in spotless condition, wipe with a warm soapy cloth. **Do not clean hot ceramic surface with a soapy cloth, use automotive chrome cleaner on cool surface.**

See page 28 for complete cleaning guide.

Caution - Product Damage Hazard

Before using any cleaners, ensure that it is suitable for application on chrome trim.

Make sure that the glass ceramic surface has cooled down before applying any cleaning materials.

1. Saving on Cleaning Time

- Make sure the bottom of pots and pans and cooking area are clean and dry.

Select correct heat settings and use saucepans large enough to accommodate food and liquid to eliminate boilovers and splattering.

- Wipe up food spills and splatters from adjacent heating areas before cooking.
- Do not drag or slide pots along the surface.

2. Daily Care

- Use a ceramic glass cleaner-conditioner, available at supermarkets and major department stores. As the cleaner-conditioner cleans, it leaves a protective coating of silicone on the smooth surface, which helps prevent scratches and abrasions in which food particles can collect. It also helps prevent the build-up of mineral deposits, and will make future cleaning easier.
- Apply a dab of cleaner-conditioner in the center of each heated area to be cleaned.
- For normal cleaning start with about 1 ml (1/8 tsp) of cleaner-conditioner, and apply more if needed.
- Clean unit with a damp clean paper towel. To remove more stubborn spots, use a slightly dampened non-impregnated plastic or nylon pad specially made for non-stick utensils.
- Wipe off this application with another clean, damp paper towel, and wipe dry.
- Use liquid cleansers to remove any discoloration, especially in hard water areas. A non-impregnated plastic or nylon pad specially made for non-stick utensils may also be used with these cleaners. Do not apply excessive pressure while rubbing. This could cause scratches over time.
- Apply cleaner-conditioner and polish with paper towel or a soft dry cloth.
- Any smearing or hazing on the surface may be removed with a lightly dampened paper towel, and polished with a soft dry cloth.
- Do not use a sponge or a dishcloth. They may leave a film of soil-laden detergent on the heating area which may turn brown and resemble a discoloration the next time the area is heated. If that should happen, cleaner-conditioner will remove it.

Warning

Personal Injury Hazard

- **NOTE:** If a wet paper towel is used to remove spillovers from warm cooking area, be careful to avoid steam burns.
- Never mix different household cleaning products. Chemical mixtures may interact, with objectionable or even hazardous results.

Do Use

Ceramic glass cleaner-conditioner should be used regularly to clean and protect glass-smooth top cooking surface. If you run out, you may temporarily use baking soda as a cleaning powder.

Do Not Use

1. Household detergents and bleaches.
2. Impregnated plastic or nylon pads.
3. Soap pads; these will scratch and mark.
4. Household abrasive powders except where specified; these may scratch depending on the pressure applied in use.
5. Chemical oven cleaners, e.g. aerosols and oven pads. These are caustic cleaners, and may etch the surface.
6. Rust stain or bath and sink stain removers, as these will mark and etch the surface.
7. Metal scrubbers.

How To Deal With Burned-On Spots

1. Make sure area to be cleaned is warm to the touch.
2. The careful use of a stainless steel razor blade held at approximately 30 degrees to the surface can be used to remove stubborn burned-on spots from the surface.
3. Use cleaner-conditioner, and finally wipe the cooktop clean with a paper towel or damp cloth.

If after the use of recommended materials there are some persistent stains or marks on the cooktop, the unit should be cleaned using a liquid cleanser. This will remove any accumulated residue of cleaner-conditioner, and if applied with a non-impregnated plastic or nylon pad for non-stick pans, for at least three to four minutes, it will also take off the film caused by salts and minerals before it has an opportunity to discolor or develop into a problems. Finish off with a touch of cleaner-conditioner, polish to a high lustre.

Any smearing or streaking on the surface may be removed with lightly dampened paper towel and polished with a soft dry cloth.

Metal Marks

Certain metal pots, especially those with aluminum bottoms may leave marks on the surface, especially if the pan is allowed to slide. Use the cleaner-conditioner before the unit is used again to prevent the mark from baking on the surface.

Caution


Product Damage Hazard

Ceramic glass cleaner-conditioner should be applied regularly after use of other cleaners, otherwise over a period of time the surface of the ceramic glass may roughen, and cleaning will become progressively more difficult. Staining may also occur.

Important Notes

1. In the event of the cooktop being scratched, soil will collect and appear as fine lines. These are not fully removable, but can be minimized by the daily use of cleaner-conditioner. These scratches do not affect cooking performance.
2. Soil from sugar solutions must be removed from the cooktop before the syrup has set, otherwise it can permanently bond to the ceramic surface.

GRIDDLE OPTION



Griddle for Smoothtop (glass top)

Set griddle over a back/front burner combination. Turn both burners on MAX for a couple of minutes or until griddle reaches frying temperature. Temperatures may be adjusted as required.

Griddle for gas burners

Set griddle on the left over the back/front burner combination. Lock the notches of the griddle onto the back & front grate fingers. First make sure that grates are positioned on burners correctly. Turn both front & back burners on to correct frying temperature.

Warning: Do not use two griddles on a range as damage to the top can occur.

CANNING

For best results, use a flat bottom, heavy gauge canner. Canners with rippled bottoms will not work on electric burners because the bottom does not make enough contact with the element.

GAS COOKTOP

Gas cooktops are more forgiving than electric cooktops. Most cookware will work, although tight fitting lids are recommended for efficient cooking on both. Always adjust the burner controls so that flames do not extend past the edges of pots or pans.

GAS BURNER CLEANING

Top Burners

Your gas range is equipped with “state of the art” “Sealed Gas Burners” and an “Auto-Reignition System”. The sealed gas burners spread the heat evenly across the bottom of the cooking utensil and provide infinite heat control. The auto-reignition system senses when a burner flame has gone out and will automatically reignite that burner. There are no standing pilots to light or adjust.

See this page for cleaning and maintenance of top burners.

Operating Range During a Power Failure

To light a top burner during a power failure, hold a lit match to the desired burner head. Turn the corresponding control knob to any numbered position. After burner lights, adjust flame to desired setting.

The gas oven requires electricity to operate.

Removal of Burner Knobs

Apply a piece of duct tape to the surface of the knob for better grip. Pull off by hand or with a pair of pliers.

Manual Burner Adjustment On Low

The burners have been pre-adjusted at the factory for best performance. You may manually adjust the low settings up or down by removing the control knob while the burner is lit and in the low position. While holding the valve stem so it doesn't turn, insert a small flat blade screwdriver into the stem and turn the small brass screw slightly in either direction until desired flame height is obtained. Valve must be adjusted so low flame licks around burner cap no less than 1/8". See figure 11.




Figure 11

Figure 12

NOTE: Low adjustment will not effect flame heights at other settings. If a top burner flame has been adjusted too low, the electronic ignitor may start to spark while burner is on. Readjust flame until ignitor stops sparking.

Flame Appearance

The burners have been pre-adjusted at the factory to a clean blue flame. On LP gas, a slight orange tip may be visible. If flame is not as above, your gas serviceman can check the regulator for proper setting with a water manometer (U-gauge). The stove pressure should be within + or - 10% of the pressure setting shown in this manual.

- **The burner caps** should be routinely removed and cleaned. Always clean burner caps after a spillover. Keeping the burner caps clean aids in proper ignition and an even flame. Set burner caps into indents in burner base.

- **For proper flow** of gas and ignition of the burner, **DO NOT ALLOW SPILLS, FOOD, CLEANING AGENTS OR ANY OTHER MATERIAL TO ENTER THE GAS ORIFICE OPENING.**

- **Gas must flow freely** through the small hole in the brass orifice for the burner to light properly. This area must be free of any soil and be kept protected from boilovers or spillovers. **ALWAYS** keep the burner caps in place whenever a surface burner is in use.

Occasionally check the burner flames for proper size and shape as shown. A good flame is blue in color. If flames lift off ports they are yellow and usually noisy. You may need to clean the burners. See figure 12.

If Ignitors Continue to Click:

If your ignitors continue to click after lighting, the probable cause is dirt or moisture around the burner, or between the burner and ignitor. Clean these areas thoroughly with household cleaner or soap and water. Dry thoroughly or sparking may still occur. (You may have to use a hair dryer to completely dry the area.) If the condition persists, but on low setting only, you may need to increase the burner flame (see “Manual Burner Adjustment” – this page). If the condition persists, check for damaged ignitors. Very rarely, the spark module may need to be replaced. Ignitors and spark modules, with installation instructions, can be ordered from Elmira Stove Works, and must be serviced from under the cook top.

To Clean Burners:

1. **Lift** the burner cap straight up from the burner base.
2. **Clean** burner cap with warm, soapy water and a sponge. You can also clean with a nonabrasive scrubbing pad or cleanser. Do not clean burner cap in dishwasher.
3. **If the gas orifice opening** has become soiled or clogged, use a cotton swab or a soft cloth to clean the area.
4. **If ports are clogged, clean** with a straight pin. **Do not enlarge or distort port. Do not leave anything stuck in the ports.**
5. **After cleaning** the orifice opening and ports, replace the burner cap. **Make sure** cap is set straight on burner and that the tabs on cap fit into the grooves of burner base.
6. **Check** the burner for proper lighting after cleaning.
7. Replace the burner cap, making sure the alignment pins on the cap are properly aligned with the burner base.

GAS SUPPLY SYSTEM

Gas and Electrical Supplies

Before connecting to the supply systems, be sure that the installation conforms with the local codes or, in the absence of local codes, with the National Fuel Code, ANSI Z223.1 latest edition or in Canada, CAN/CGA B149 installation codes. See page 4 for electrical requirements.

Gas Piping to Range

The gas supply piping to the range should be 3/4" pipe which is then reduced to 1/2" at the regulator. With "LP" gas, the size of the piping to the range should be determined by your gas fitter.

When connecting pipe to the die cast regulator fitting, use two wrenches. Excess pressure or tightening the pipe too tight can cause the regulator to crack, resulting in a gas leak or a possible fire or explosion.

Make sure that if flexible connectors are used in connecting the appliance to the gas supply, they are AGA and/or CGA approved. Poorly designed connectors can be a source of gas leaks. Even if AGA/CGA approved flexible connectors are used, the customer should be cautioned against kinking or damaging the connection when moving or cleaning the range. This could cause a gas leak.

Manual Shutoff

Install a manual shutoff valve in the gas line, in an accessible location, near the unit. Know where the gas valve is so you can shut off the gas to the range quickly. Suitable pipe thread sealant must be used which is approved for use with "LP"/Natural gas. Be sure to use this thread sealant on all pipe connections.

Pressure Testing


The appliance, and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/3 psig (3.5kPa).

The appliance must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply system at test pressures equal to or less than 1/2 psig (3.5kPa).

The gas supply pressure for checking the regulator setting shall be at least one inch w.c. above manufacturer's specified manifold pressure.

Gas Leak Testing

After the final gas connection has been made, all the top burner valves should be closed and the gas supply and manual shutoff turned on. All connections in the gas supply line and in the range should be tested with soap suds or electronic sniffer for leaks. If a leak is present, bubbles will appear. The leak should be stopped



A. Incorrect
B. Correct

8. Turn on the burner. If the burner does not light, check cap alignment. If the burner still does not light, do not service the sealed burner yourself. Contact a trained repair specialist.

NOTE: If a gas burner burns with an uneven orange flame, reposition the burner cap so it sits flat on the burner housing. If burner lights slowly, have your gas service person check the gas pressure to the appliance.

If a top burner flame has been adjusted too low, the electronic ignitor may start to spark. Readjust flame until ignitor stops sparking.

When cleaning around the surface burner, use care. If cleaning cloth should catch the ignitor, it could damage it, preventing ignition.


If surface burner does not light, check if ignitor is broken, soiled or wet. If clogged, clean the small port beneath the ignitor using a straight pin.

Wipe acid or sugar spills as soon as the cooktop has cooled as these spills will discolor the porcelain.

See Cleaning Guide – Page 28.

OVEN VENTING - GAS TOP MODELS

The Oven Vent



Hot air and moisture escape from the oven through a vent in the center rear of the cooktop. **Do not block the vent.** Poor baking/roasting and bad combustion can result. The oven bottom must be in place for burner to bake properly on model 1956.

by tightening the joint, or unscrewing completely and applying additional pipe dope and re-tightened. Any factory connections which may have been disturbed should be retested.

A match should never be used when testing for leaks. All fittings have been tightened and tested at the factory. If a leak is detected, tighten the fitting. Don't use pipe dope on factory fittings.

RANGE TOP CONVERSION TO "LP"

Models 1955 & 1956

All our ranges are factory set to burn natural gas unless "LP" is specified. To use the range on "LP" gas, please do the following:

Order an "LP" kit from the factory. \$35 UPS included.


Burner	Large	Medium	Small
Nat. Gas	#50 (1.75 mm)	#55 (1.32 mm)	#57 (1.09 mm)
LP/Propane	#64 (.91 mm)	#65 (.89 mm)	#70 (.71 mm)

Store natural gas spuds so they are available for future conversions.

Installation of "LP" Spuds

Apply masking tape to the end of a 7 mm nut driver to help hold the gas orifice spud in the nut driver while changing it. Press nut driver down onto the gas orifice spud and remove by turning it counterclockwise and lifting out, set gas orifice spud aside.

Gas orifice spuds are stamped with a number on the side. Replace the LP gas orifice spud with the correct Natural gas orifice spud.



Refer to the following chart for the correct Natural gas orifice spud placement.

Conversion of Regulator to "LP" on Model 1955

Disconnect Power to Range

- Open oven door and remove it, see removal instructions on page 16.
- With a Philips driver, undo the 2 screws holding the top down.

- Pull top forward about 2" then lift front. Raise the service stay on each side to hold the top up.
- On the back right of the range unscrew the nut on top of the regulator.
- Reverse the white insert pin by pulling it out of the cap, reverse it, then snap it back into the cap. Replace cap into body of regulator and tighten, making sure not to disturb the regulator spring.





Figure 13 NAT. GAS

LP GAS

Replacing rangetop orifices


Tools required to replace orifices.

Small adjustable wrench.

1. Remove the lift off burner cap.
2. With the small adjustable wrench, unscrew the brass venturi and remove.
3. Unscrew the natural gas orifices in each of the top burners using the 7mm nut driver included with orifice kit. Replace with "LP" orifices listed below.


	Nat. Gas	LP/Propane
Front left superburner takes	1.75 mm (#50)	.91 mm (#64)
Other front burners take	1.32 mm (#55)	.89 mm (#65)
All rear burners use	1.09 mm (#57)	.71 mm (#70)

Note: example. Orifices are stamped metric sizes. (00) is the number drill equivalent.



4. Reinstall the brass venturi.
Store nat. gas orifices and nut driver so they are available for future conversions.
When replacing the black caps, make sure that the tabs in the cap fit into the grooves of the burner base.


OVEN CONVERSION MODEL 1956



Warning – Fire Hazard

- Locate gas supply shut off valve on the pressure regulator.
- Shut off gas supply before converting to L.P. gas.
- Make all conversions before turning gas supply valve back on.

Failure to follow these instructions could result in fire, explosion or other personal injury.




- A. PLASTIC COVER
- B. GAS PRESSURE REGULATOR CAP WITH SOLID END FACING OUT
- C. GAS PRESSURE REGULATOR CAP WITH HOLLOW END FACING OUT
- D. WASHER
- E. GAS PRESSURE REGULATOR CAP

Conversion of Regulator to “LP” on Model 1956 (gas oven)

- Remove storage drawer. See page 17.
- Locate the regulator at the rear of storage drawer compartment.
- Remove the plastic cover from the regulator cap.
- With your fingers, turn the nut counter clockwise.
- Do not remove the spring beneath the cap.
- Turn the cap over so LP faces up and reinstall into regulator.
- Replace plastic cover over regulator cap.

To Convert Oven Bake and Broil Burner


1. Remove oven racks.
2. Use a 1/2” combination wrench to tighten the orifice hood toward the pin (about 2 to 2-1/2 turns). The oven bake burner flame cannot be properly adjusted if this conversion is not made.



- A. ORIFICE HOOD
- B. PIN
- C. NATURAL GAS: INCREASE GAS – INCREASE FLAME SIZE (PRESET AT FACTORY FOR NATURAL GAS)
- D. LP GAS: DECREASE GAS, DECREASE FLAME SIZE.

To Convert Oven Broiler Burner

1. Use a 1/2” combination wrench to tighten the orifice hood toward the pin (about 2 to 2-1/2 turns). The oven broil burner flame cannot be properly adjusted if this conversion is not made. See “Adjust Oven Broil Burner Flame” section.



2. Reinstall the storage or warming drawer.
3. Complete installation. See “Make Gas Connection” and “Electronic Ignition System” sections.


Checking for proper cooktop burner and oven bake burner flame is very important. Natural gas flames do not have yellow tips.

IMPORTANT: You may have to adjust “LO” setting for each cooktop burner.

If the “low” flame needs to be adjusted:

Standard Burner Adjustment

The flame can be adjusted using the adjustment screw in the center of the valve stem. The valve stem is located directly underneath the control knob.




A. Adjustment screw

1. Remove the control knob.
2. Hold the knob stem with a pair of pliers. Use a small flatblade screwdriver to turn the screw located in the center of the control knob stem until the flame is the proper size.
3. Replace the control knob.
4. Test the flame by turning the control from “LO” to “HI,” checking the flame at each setting.

Check Operation of Oven Broil Burner

1. Close the oven door.
2. Set selector to broil, and thermostat to broil.

The oven burner should light within 8 seconds, under certain conditions it may take the burner up to 50 to 60 seconds to light.




A. Gas burner

NOTE: Oven door must be shut for broil burner to operate.

Adjust Oven Broil Burner Flame (if needed)

Look through oven window to check broil burner for proper flame. This flame should have a 1/2” (1.3 cm) long inner cone of bluish-green, with an outer mantle of dark blue, and should be clean and soft in character. No yellow tips, blowing or lifting of flame should occur.




A. Lock screw

If flame needs to be adjusted:

1. Loosen the lock screw on the air shutter located at the rear of the broil burner.
2. Adjust the air shutter as need.
3. Tighten lock screw.

SETTING CLOCK – ALL MODELS



Setting clock initially or after power failure (if control is flashing)

1. To set time: Touch UP or DOWN button until correct time is shown.

Resetting time (if control is not flashing)

2. Push SELECT 5 times until CLOCK light is illuminated. Push UP or DOWN until correct time is shown.

NOTE: You must act within 3 seconds or the function you are trying to set will cancel.

SETTING MINUTE TIMER:

1. Touch SELECT once. 00:00 will appear. Within 3 seconds press UP for time in minutes.

BAKE OR BROIL

Turn Selector switch to bake or broil. Set oven thermostat to desired temperature.

Preheating oven on bake normally takes about 15 minutes, indicator cycle light will go out when oven has reached temperature. The Broiler takes about 3 minutes to preheat. After preheating, broiler may be set to variable temperatures by adjusting the thermostat.

DELAYED BAKE

(Oven turns on and off automatically):

1. Touch SELECT 2 times. Current time will flash. Press UP until the correct START TIME has been reached. Wait 3 seconds. Touch SELECT once. COOKTIME will appear. Press UP until the proper cooktime has been reached. Set the oven selector to AUTO and thermostat to the correct temperature.

TIMED BAKE

(Oven turns off automatically):

1. Touch SELECT 3 times. COOKTIME will appear. Press UP until the proper cooktime has been reached. Set the oven selector to AUTO and the thermostat to the correct temperature.

NOTE: On delayed bake and time bake allow an extra 12 minutes for oven to preheat.

OVEN LIGHT

Press LIGHT. Oven lights will turn on or off.

CLOCK vs. DIGITAL DISPLAY


If Clock does not agree with Digital Display

1. Press SELECT 5 times. Clock indicator will illuminate.
2. Press UP and DOWN arrows at the same time.
3. Adjust analog hands UP or DOWN to correct time.
4. 12:00 will appear on the display after 3 seconds.
5. Adjust digital time UP or DOWN to match the clock hands. (start within 3 seconds)

SELF CLEAN

1. Touch SELECT 4 times. CLEAN will appear and 3:00 will be displayed on clock. Although we recommend 3:00 for most oven cleaning, by selecting UP or DOWN you can change the length of the clean cycle.

Set the oven selector and thermostat to CLEAN. Within 10 seconds the door will lock and the oven will start to clean. If you want to cancel oven cleaning press cancel. If the oven has reached 575°F the oven door can only be opened after a 30 minute cool down as shown on the clock. It is a good idea to remove oven racks before cleaning oven as they will become discolored.



Before You Start Self Cleaning

- **Hand-clean** the areas shown. They do not get hot enough during the cleaning cycle for soil to burn away, and could get baked on during cleaning. Use hot water and detergent or a soapy steel-wool pad for cleaning. Oven cleaners may be used in oven but must be completely removed before self-cleaning cycle begins.

NOTE: Do not clean, move or bend the gasket. Poor cleaning, baking and roasting may result.

- **Wipe out** any loose soil or grease. This will help reduce smoke during the cleaning cycle.
- **Remove** the broiler pan grid and anything else being stored in the oven.

NOTE: If oven racks are cleaned in the self-cleaning cycle, they will become discoloured and more difficult to slide.

If you clean racks in the self-cleaning cycle, place them on the 2nd, 3rd and 4th rack guides.

For Best Cleaning Results

- **Clean the oven before** it gets heavily soiled. Cleaning a very soiled oven takes longer and results in more smoke than usual.
- **After the oven is cool, wipe up** any residue or ash with a damp cloth or sponge. If any spots remain, clean with a mild abrasive cleaners or mildly abrasive pad.
- **If the self-cleaning cycle does not get the oven as clean as you expected**, the cycle may not have been set long enough or you may not have prepared the oven properly. Set the self-cleaning cycle longer the next time and hand-clean areas noted above.

By turning exhaust fan on while self-cleaning most smoke and odor in kitchen will be eliminated.

Automatic Door Lock

As soon as you program the oven for the self-cleaning function, the door will automatically lock. It will remain locked throughout the entire cycle. The door will automatically unlock when the temperature lowers to a safe level.


Important: After self cleaning the oven, the oven selector knob must be left in the clean position until the oven has cooled down and the door has unlocked. If you have turned the selector off prior to the door unlocking, turn the selector and control to “Clean”. The door will unlock. You can then turn the selector to “Off”.

MAINTENANCE & MINOR REPAIR

Removable Oven Door

The oven door is removable to allow easier manual cleaning inside the oven if desired.

Removing the Oven Door:



Completely open oven door. In both back corners of the door you will see door latches in the locked position. Rotate both latches forward to the unlocked position.

Grasp outside edges of door with both hands.

- Begin closing door, at the moment the door stops closing, lift and pull door toward you.
- Set door aside on a protective surface.

Resetting Breakers

In case of a stove malfunction, try resetting the breaker, at the main breaker panel.


Clock Malfunction

If you have experienced a power surge or loss of power recently, your clock may have “locked up”. Turn power off to your range for about 15 seconds then reconnect. This should reset clock/control and it should now function normally.

REPLACING OVEN LIGHTS

To Replace Oven Light on Model 1956:

1. Unplug appliance or disconnect at the main power supply.




2. Replace the oven lights with a #4452166 15W appliance bulb. These bulbs are available from a Whirlpool/KitchenAid dealer or from Elmira Stove Works.
3. All cabinet lights are the rectangular 12 volt 5 watt variety as shown below.

To Replace Oven Lights on all Models but 1956:

Lights on the range are 12-volt, 5-watt (maximum) halogen bulbs.

Before replacing, make sure the oven is off and cool

1. Disconnect power.
2. Remove glass light cover by grasping the front edge and pulling away from oven.



3. Remove bulb from socket. Do not touch bulb with fingers.
4. Replace bulb, replace bulb cover by snapping back into wall.
5. Reconnect power.

Lubrication

Lubricate the following with white lubricant:

- Oven door hinges (if they squeak).
- If burner control knobs stick, remove knobs and lubricate around switch shaft with a small amount of white lube. Replace knobs on switches.

IMPORTANT

If in doubt about how to handle service, call us at the factory for help at: 1-800-295-8498.

OPTIONAL – WARMER DRAWER

WARMING DRAWER CONTROLS

Setting the Temperature

Turn the warmer thermostat knob to the desired setting. Temperatures can range from 80 degrees to 225 degrees.

WARNING: Food Poisoning Hazard! Do not let food sit for more than one hour before or after cooking. Doing so can result in food poisoning or sickness.

Moist-Dry Slide

The Moist-Dry slide allows you to open or close the vent slots in the door. The MOIST setting holds moisture in, while the DRY setting allows steam and moisture to escape from the drawer.

To keep foods moist, put slide on MOIST, closing the vents. Closing the vents will seal the drawer and keep hot food soft and moist.

To keep foods crisp, put slide on DRY, opening the vents. Opening the vents releases moisture from the drawer and keeps hot food crisp and dry.

The warming drawer is ideal for keeping hot cooked foods at serving temperature. It may also be used for warming breads and pastries.

Different types of food may be placed in the warming drawer at the same time. For best results, do not hold food longer than one hour. For small quantities or heat-sensitive foods (such as eggs), do not hold longer than 30 minutes.

Food must be at serving temperature before being placed in the warming drawer. (Breads, pastries, and fruit pies may be heated from room temperature on the HI setting.)

Remove food from plastic bags and place in oven-safe container. Cover foods with a lid or aluminum foil. Do not cover with plastic wrap. Empty serving dishes and dinner plates can be heated while the warming drawer is preheating.

Storage or Warmer Drawer Removal Instructions

- If the storage or warmer drawer is not removed or installed properly, ball bearing race could be damaged.

- DO NOT REMOVE THE DRAWER UNLESS ABSOLUTELY NECESSARY.
- If removing drawer, pull it out to the stop.
- Slide the black nylon tab on each side towards you.
- Slowly pull the drawer straight out of the ball bearing track.
- When reinstalling the drawer, extend the ball bearing track inside the stove fully towards you.
- It works best with 2 people, one on each side of the drawer.
- Slowly push drawer straight into the track until it is fully closed.
- Drawer should now open and close freely.

Proofing Bread

Proofing bread prepares dough for baking by activating the yeast. Proofing twice is recommended.

To Proof:

1. Cover dough with lightly oiled wax paper and place temperature safe bowl(s) directly on bottom of drawer.
2. Set control knob to 80°F
3. Place vent on MOIST setting.
4. Check dough periodically for proofing progress.
5. Verify doneness by pressing 2 fingers 1/2” (1.27 cm) into dough. If indentation remains, the dough is ready.

For second proofing of dough, follow steps 1-4.

Warming Tips

- Do not line warming drawer with aluminum foil.
- Keep food covered if it was cooked with a cover on it.
- Use narrow strips of foil to shield pie crust edges from further browning in drawer.
- Place tent-shaped foil loosely over meat or poultry to prevent dryness and further browning while in the drawer.
- The use of aluminum foil to cover foods may cause moisture to collect and drip into the drawer.

CONVECTION COOKING TIPS

(For Convection Models)

To learn how to use your convection oven to the best advantage, refer to *Convection Cooking* on page 23.

1. The fan-forced hot air movement permits baking and roasting on as many as 3 levels at once.
2. The Delay feature can not be used when using *Convection* for baked items e.g....pies, cakes, cookies.
3. There should be a minimum of 1" (2.5 cm) between the walls and the pans used.
4. Position food in oven to allow free flow of air around the convection fan.
5. Uniform spacing of baking dishes will produce the most even results.
6. Place bread pans lengthwise facing the oven door.
7. Do not use aluminum foil for convection baking. It may block airflow.
8. True convection cooking is used for baking breads, cakes and other foods which require gentle heating. This setting is also recommended when baking large quantities of food on more than one rack.

Note: During convection cooking, the oven door must remain closed. The fan will operate only when the door is closed.

Convection cooking creates more moisture in the kitchen than normal, usually because more food is being cooked at one time. We suggest that the exhaust blower be set on low when convection cooking.


9. For convection roasting, do not use a roasting pan with high sides, as it cuts down the free flow of air circulating around the food. Use the convection roasting rack on the broiler pan.
10. Convection cooking of frozen convenience foods:
 - Preheating the oven is not necessary.
 - Cooking times will be similar to package recommendations. Follow suggestions for oven temperatures and use of cookie sheets and foil coverings.
 - Most foods are best placed in the middle of the oven.
 - If more than one item is being cooked, stagger foods on multiple racks for proper air circulation.

Closed Door Broiling only

2. **Use the broiler pan and grid for broiling.** They are designed to drain excess liquid and fat away from the cooking surface to help prevent spatter, smoke and fire.
3. Turn food only once during broiling. Using tongs to turn meats prevents loss of juices. Use *Minute Timer* for timing each side.

Roasting tips

- **Roast** meats fat-side up in a shallow pan using a roasting rack.
- **Use a roasting pan** that fits the size of the food to be roasted. Meat juices may overflow the sides of a pan that is too small. Too large of a pan will result in increased over spatter.
- **Spatter can be reduced** by lining the bottom of the roasting pan with lightly crushed aluminum foil.



- **A foil tent** will slow down surface browning for long-term roasting, as when roasting a turkey. Place tent-shaped foil loosely over meat to allow for air circulation. Do not seal foil or meat will be steamed.
- **Use an accurate meat thermometer** to determine when meat has reached desired degree of doneness. Insert the thermometer into the center of the thickest portion of the meat or inner thigh or breast of poultry. For an accurate reading, the tip of the thermometer should not touch fat, bone or gristle.
- **After reading the thermometer once**, push it further into the meat 1/2 inch or more and read again. If the temperature drops, return the meat to the oven for more cooking.
- **Check pork and poultry** with a thermometer in 2-3 places to ensure adequate doneness.
- **Poultry and roasts will be easier to carve** if loosely covered with foil and allowed to stand 10-15 minutes after removal from the oven.


Convection Broiling

(On Convection Models)

1. **Keep the oven door closed.**
2. **Use the convection roasting rack and broiler pan for convection broiling.** Convection broiling is essentially high-temperature convection cooking, combining fan-circulated hot air with the direct heat of the broiler element.
3. Do not cover the roasting rack with tin foil as this will block air flow and extend cooking time.
4. The circulating air creates a seal on all sides of the food so that turning of foods is often not necessary.

General Broiling Tips

1. The surface of the food should be at least 3" (7.4 cm) away from the broil element.
2. For steaks and chops, slash fat evenly, at 2" (5 cm) intervals, around the outside edges of meat to prevent curling.
3. Meats and poultry can be marinated before broiling. Brush foods with barbecue sauce only during the last 5 to 10 minutes of broiling.
4. Place food on a cold pan to prevent sticking. If the rack is hot, grease it or grease the food.




NOTE: Opening the oven door will cause heat loss, longer cooking times and unsatisfactory baking or roasting results. Rely on your timer.

Convection Roasting Rack

(On Convection Models)

The Convection Roasting Rack is a specially designed rack, ideal for use when roasting and broiling meats using the *Convection Bake* and *Convection Broil* functions. Place it in the broiler pan instead of the regular grid. It raises the meat for better airflow to all sides for more even roasting and broiling.



Air Circulation

The hot air must circulate around the pans in the oven for even heat to reach all parts of the oven. This results in better baking.


For best air circulation:

- Place the pans so that one is not directly over the other.
- For best results, allow 1-1/2" to 2" (3.7-5 cm) of space around each pan and between pans and oven walls. There must be a minimum space of 1" (2.6 cm).




- When baking with one pan, place pan in the center of the oven rack.
- When baking with two pans, place pans in opposite corners of the oven rack.

Oven Rack Positions



Your oven has five rack positions. Rack position 1 is the lowest position, or closest to the bottom of the oven. Rack position 5 is the highest position, or farthest from the bottom of the oven.

There are three straight racks. Be sure to position the oven rack(s) before putting food into the oven or turning the oven on.



To remove oven racks:

Lift rack at front and pull out.

To replace oven racks:

1. Place rear of rack on rack guides.
2. While lifting front of rack, push in all the way. Lower front.

**For Proper Cooking,
Follow These Guidelines:**

- **When using one rack**, place the rack so the **top of the food** will be centered in the oven.
- **When using two racks**, place racks in positions 3 and 1 (the closest to the oven bottom).
- **Use only one cookie sheet** in the oven at a time when using the regular Bake setting.

Rack Placement for Specific Foods:

(For rack positions, see “Rack Positions” on page 19.)


FOOD	RACK POSITION
Frozen Pies	1 or 2
Angel and bundt cakes, most quick breads, yeast breads, casseroles, meats	2
Cookies, biscuits, muffins, cakes, non frozen pies	2 or 3

Using Aluminum Foil in the Oven

Do not use aluminum foil for convection cooking. Aluminum foil may block airflow.

Do not cover the broiler grid with foil. Poor drainage of grease may result in a fire.

When using aluminum foil for **non-convection cooking** to catch spillovers from pies or casseroles, follow these instructions.



- **Place the foil on the oven rack below the rack with the food.** Turn foil edges up and make sure foil is about 1 inch (2.5 cm) larger all around than the dish holding the food.
- **Do not cover the entire rack** with aluminum foil. It will reduce air circulation and cause poor cooking results.

The self-cleaning cycle operates with the easy-to-use clock control. See page 14.

STANDARD OVEN MEAT ROASTING CHART

- Roast at oven temperature of 325°F.*

*For chicken, set the oven temperature to 350°F.

Preheating is not needed.

- Place roasting pan on rack position 1 or 2. See page 19 for rack positions.

MEAT	APPROXIMATE WEIGHT	APPROXIMATE MINUTES PER POUND	MEAT THERMOMETER TEMPERATURE
Beef			
rolled rib	3-5 lbs		
• rare		25-29	140°F
• medium		35-37	160°F
• well-done		45-47	170°F
standing rib	6-7 lbs		
• rare		23-25	140°F
• medium		30-32	160°F
• well-done		35-40	170°F
rump roast	4-6 lbs		
• medium		25-30	160°F
• well-done		35-37	170°F
Lamb			
leg	6-7 lbs		
• rare		18-29	140°F
• medium		21-24	150-155°F
• well-done		30-32	180°F
Pork			
loin	3-4 lbs	45-48	170°F
	5-6 lbs	40-44	185°F
shoulder	4-5 lbs	40-44	185°F
ham, fully cooked	3-5 lbs	17-18	130°F
	8-10 lbs	13-14	130°F
Poultry			
chicken*	3-4 lbs	28-30	185°F
turkey, unstuffed	10-16 lbs	14-19	170-180°F
	18-25 lbs	11-15	170-180°F
Veal			
loin	3-4 lbs	35-38	170°F
shoulder	5-6 lbs	43-45	170°F

STANDARD OVEN BAKING CHART

Food	Oven Temperature	Approximate Cooking Time (Minutes)
Breads, yeast		
• loaf	375°F	30-40
• rolls, pan	400°F	12-15
Breads, quick		
• biscuits	450°F	10-15
• muffins	400°F	20-25
• popovers	450°F	20-25
• corn bread	425°F	25-30
• nut bread	350°F	60-75
• gingerbread	350°F	25-30
Cakes		
• angel food	375°F	30-40
• layer cake	350-375°F	20-30
• loaf cake	350°F	35-45
• sponge cake	350°F	35-45
• pound cake	350°F	34-45
• fruit cake	300°F	2-2 1/2 hrs
• sheet cake	300°F	25-35
Cookies		
• drop	375°F	10-15
• rolled and refrigerated	375°F	8-12
• chocolate	375°F	10-15
• fruit and molasses	375°F	10-15
• brownies	350°F	20-30
• macaroons	350°F	12-15

Food	Oven Temperature	Approximate Cooking Time (Minutes)
Miscellaneous		
• apples, baked	375°F	50-60
• beans, baked	300°F	5-6 hrs
• custard, cup	325°F	35-40
• potatoes, baked	400°F	75
• pudding		
• bread	350°F	45-60
• cottage	375°F	30-40
• rice	325°F	40-60
• scalloped dishes	350°F	60-90
• soufflé	350°F	50-60
Pastries		
• cream puffs	400°F	35-40
• custard and pumpkin pie	350°F	30-40
• pastry shell	450°F	10-12
• two crust fruit pie		
cooked filling	400°F	25-30
uncooked filling	400°F	40-50
• meringue topping	350°F	10-15
Temperatures and times are guidelines only and may need to be adjusted to individual tastes.		

Broiling Chart:

The recommended rack position is numbered lowest (1) to highest (5). Preheat broiler for five minutes before placing food in oven.

MEAT	RACK POSITION	TEMPERATURE	APPROXIMATE TIME (MINUTES)	
			SIDE 1	SIDE 2
Steak, 1" thick	4	500°F		
• rare			4	4
• medium			6	6
• well-done			8	8
Steak, 1 1/2" thick	4	500°F		
• rare			8	8
• medium			10	10
Hamburger patties or steaks, 1/2" thick or less				
• medium	4	500°F	6	4
Lamb chops, 1" thick	4	400°F	9	9
Ham slice, 1/2" thick	4	500°F	5	5
precooked 1" thick	4	500°F	10	10
Pork chops, 1" thick	4	450°F	12	12
Frankfurters	4	500°F	4	4
Chicken pieces	3	500°F	16	16
Fish, 1" thick	3	350°F	10	10
Beef liver, 1/2" thick	4	350°F	5	5

Temperatures and times are guidelines only and may need to be adjusted to individual tastes.

INTRODUCTION TO CONVECTION COOKING


Welcome to convection cooking, the ultimate culinary technique that uses fan-circulated hot air to efficiently create delicious meals with appetite appeal.

Air Flow

The secret to convection cooking lies in maintaining a consistent temperature throughout the oven during the cooking process. The fan circulates hot air in your convection oven continually to distribute heat more evenly than the natural movement of air. This fundamental difference means food is cooked on all sides, sealing in natural flavour and moisture. Avoid blocking the air circulation fan at the rear of the oven with a large dish, as this will interrupt free flow of air throughout the oven. It is important not to cover foods with foil, so that surface areas remain exposed to the moving air. The effective use of circulating air also means that many of your convection creations require shorter cooking times at lower oven temperatures, so you enjoy the added benefits of less time spent in the kitchen, and greater energy savings.

Preheating

When preheating the oven is specified in a recipe, normal time is approximately 15 minutes.



Multi-Level Convection Cooking

An immediate practical benefit of the convection cooking method is that hot air movement allows you to load the oven racks to capacity. For instance, you can bake four loaves of bread as quickly as you might finish two, with outstanding, uniform results. You may choose to cook your main course and side dishes or dessert, at the same time. For greatest success with multi-level cooking, stagger dishes on opposite corners of the oven racks to the ones above and below. Be

CONVECTION MEAT ROASTING CHART

Set Cooking Selections to: CONVECTION/BAKE
R - Rare M - Medium WD - Well Done

FOOD	APPROXIMATE COOKING TIME PER LB. (500G)	RACK POSITION	OVEN TEMPERATURE	INTERNAL TEMPERATURE OF MEAT WHEN COOKED
Beef				
Standing Prime Rib	R - 20-25 min M - 25-30 min WD - 30-35 min	2	300°F/145°C	140°F/60°C 160°F/70°C 170°F/75°C
Rolled Rib	R - 22-25 min M - 27-30 min WD - 32-35 min	2	300°F/145°C	140°F/60°C 160°F/70°C 170°F/75°C
Rump, Sirloin Tip	R - 20-25 min M - 25-30 min WD - 30-35 min	2	300°F/145°C	140°F/60°C 160°F/70°C 170°F/75°C
Pot Roast (braised)	35-40 min	2	300°F/145°C	170°F/75°C
Meatloaf	20-25 min	2	325°F/160°C	170°F/75°C
Veal				
Leg, Loin, Rib	M - 25-35 min	2	325°F/160°C	160°F/70°C
Shoulder, Blade	WD - 30-40 min	2	300°F/145°C	170°F/75°C
Pork				
Loin	30-40 min	2	325°F/160°C	170°F/75°C
Shoulder	35-40 min	2	325°F/160°C	170°F/75°C
Tenderloin	25-30 min	2	325°F/160°C	170°F/75°C
Ham				
Fresh (uncooked)	25-35 min	2	300°F/145°C	170°F/75°C
Pre-cooked	15-20 min	2	300°F/145°C	140°F/60°C
Lamb				
Leg, Shoulder	M - 25-30 min WD - 30-35 min	2 2	300°F/145°C	160°F/70°C 170°F/75°C
Rib, Rack, Loin	M - 20-25 min WD - 25-30 min	2 2	300°F/145°C	160°F/70°C 170°F/75°C

sure to leave at least one inch (2.5 cm) of space between the individual pans, and the diagram shown here indicates which convection feature and rack position you should be using for that particular recipe. At the Convection setting, the center element surrounding the fan at the rear of the oven is on. At the Convection/Broil setting, the top element in the oven will heat up. At the Convection/Bake setting, the lower element will be in use. Rack positions number from 1 at the bottom to 5 at the top.

Convection Baking and Roasting

Your convection oven utilizes precise, consistent temperature control to ensure absolutely even baking and roasting results. In particular, foods that require browning are greatly enhanced by the hot air convection cooking method. Depending on the quantities you wish to prepare, convection cooked foods can be positioned on single or multiple racks. When roasting whole poultry or large cuts of meat, you can effectively lower oven temperature settings, and substantially reduce cooking times. You will notice the remarkable difference in convection cooked foods.

Memorable Meats

Convection cooking techniques contribute special appeal to your meat dishes by locking in flavour and retaining moisture. The result is meat that is evenly browned outside and tender and naturally juicy inside.

Before roasting or broiling, brush the entire surface of lean meats with butter or oil. This will increase moisture retention and enhance browning. Position cuts of meat, uncovered, on the raised convection roasting rack, so that heat freely reaches all sides.

Convection oven methods can conveniently reduce the length of time required to roast meats, in comparison to conventional roasting. Therefore, meat should be checked shortly before the end of recommended cooking times, to avoid over-cooking.

Insert an accurate meat thermometer into the thickest part of the meat, taking care to avoid any bone, fat or gristle. Once the desired internal temperature is reached, remove the meat from the oven and let stand for a few minutes. This allows the juices to settle for easier carving.

Convection Broiling

Convection broiling is essentially high-temperature convection cooking, combining fan-circulated hot air with the direct heat of the broiler element. We recommend preheating your oven first to maintain an even temperature during cooking. Convection broiling times will depend upon the variable temperature selected and the rack position used. Do not cover the broiling rack with tin foil as this will block air flow and extend cooking time. The oven door must remain closed while convection broiling. Circulating air creates a seal on all sides of the food so that turning foods is often not necessary.

Bakeware Selection

Bakeware with lower sides allows for constant air circulation around all surface areas of food, for more even cooking. High-sided casserole dishes and bread pans should be positioned on the lower racks in the oven where they will benefit from optimal heat distribution. For the most appetizing browning results, use matte or dull finish metal pans as they conduct heat more efficiently. Dark finishes on bakeware will absorb more heat than reflective surfaces, resulting in darker, crispy bottom crusts more suitable for pies and breads. Shiny muffin tins, cake pans and cookie sheets tend to reflect heat, producing light, tender crusts. Glass, ceramic, and stainless steel dishes may not transmit heat as evenly as metal bakeware.

Perfect Poultry

Preheating your oven to cook poultry is often not necessary, but we do suggest that you consult your individual recipes first. As you will notice in the Convection Poultry Roasting Chart, convection roasting temperatures are generally 25°F (15°C) lower than those used in conventional ovens.

Poultry is completely cooked when an accurate meat thermometer, inserted at the thickest part of the breast or inner thigh, registers 185°F (85°C). The juices will run clear and the meat should pull easily away from the bone.

Glazes or sauces may be brushed onto poultry during the last half of cooking time, for the perfect finishing touch.

Delicate Fish & Seafood

A limitless variety of fish and seafood can be elegantly prepared using different convection cooking methods. Variable Convection/Broil temperature settings offer you greater diversity compared to conventional broiling.

Before Convection/Broiling we recommend that you baste all surface areas of your fish and seafood with oil or butter. Reduce your oven temperature for broiling thin fillets, and use a higher setting for broiling thicker fish steaks. Lower temperatures may require longer cooking times, but thorough hot air circulation eliminates the need to handle or turn fragile fish during convection cooking.

Testing fish and seafood during the last few minutes of recommended cooking time will ensure flawless results without over-cooking. When the fish is opaque and flakes easily, remove from the oven and serve.

Savory Vegetables & Side Dishes

Oven-baking your vegetables is no longer limited to potatoes! Take full advantage of multi-level cooking and simultaneously prepare appetizing, piping hot accompaniments to your main meal with no cross-over flavors. Continuous heat distribution throughout your convection oven offers you the opportunity to efficiently prepare a variety of side dishes and vegetables.

As you prepare your own favorites, remember that more dense rice and pasta casseroles may require longer cooking times. To allow for thoroughly cooked centers without over-browned outside edges, lower oven temperatures at least 25°F (15°C), but not lower than 300°F (145°C).

CONVECTION POULTRY ROASTING CHART

Set Cooking Selections to: TRUE CONVECTION

FOOD	APPROXIMATE WEIGHT	APPROXIMATE COOKING TIME PER LB. (500g)	RACK POSITION	OVEN TEMPERATURE NOT PREHEATED	INTERNAL TEMPERATURE OF POULTRY WHEN COOKED
Chicken, Whole	3 - 5 lb. (1.5 - 2.2 kg)	20-25 min	2	325°F/160°C	185°F/85°C
Parts, Quarters	3 lb. (1.5 kg)	18-25 min	2 or 3	325°F/160°C	185°F/85°C
Turkey, Unstuffed	13 lb. and under (5.85 kg)	10-15 min	2	300°F/145°C	185°F/85°C
	over 13 lb. (5.85 kg)	10-12 min	1 or 2	300°F/145°C	185°F/85°C
Capon, Unstuffed	4 - 7 lb. (1.8 - 3.1 kg)	15-20 min	2	325°F/160°C	185°F/85°C
Domestic Duck	3 - 5 lb. (1.5 - 2.2 kg)	25-30 min then 15 min	2	325°F/160°C 400°F/205°C	185°F/85°C 185°F/85°C
Domestic Goose	4 - 8 lb. (1.8 - 3.6 kg)	30-35 min	2	300°F/145°C	185°F/85°C
Cornish Hen	1 - 1.5 lb. (0.5 - 0.7 kg)	50-60 min	2 or 3	325°F/160°C	185°F/85°C

Stuffed poultry may require additional cooking time.

Incredible Egg & Cheese Dishes

You'll be delighted with the significant difference convection cooking makes, particularly to the preparation of dishes that are sensitive to fluctuations in oven temperature.

With a consistently maintained temperature throughout the oven, a fabulous soufflé, with a light-textured interior and an exquisitely golden crust, will no longer elude you. You'll enjoy complete success creating ham and swiss cheese soufflé as egg whites rise evenly while the wonderful flavour of cheese is gently blending in.

Most egg and cheese dishes bake higher and lighter using the constantly moving air in a convection oven. Positioning dishes in the center of the oven makes efficient use of evenly distributed heat, guaranteeing perfect results with your egg and cheese dishes.

Effortless Quick Breads

Whether your family's preference leans toward delicious snack muffins or a hearty fruit and nut loaf, your convection range makes baking their favourites easy and rewarding!

Using a preheated oven will ensure quick breads are completely cooked in the center and delicately browned outside.

Enhanced heat distribution during convection baking may finish smaller items, such as biscuits and muffins, sooner than you might anticipate. Check for the desired level of doneness shortly before the end of recommended cooking times.

The moisture content and density of quick breads require convection oven temperatures within the same range as conventional baking temperatures.

CONVECTION YEAST BREAD BAKING CHART

Set Cooking Selections to: TRUE CONVECTION

FOOD	SIZE OF BAKING DISH	RACK POSITION	PREHEATED OVEN TEMPERATURE	APPROXIMATE COOKING TIME
Yeast Breads				
Loaves	Bread Pans 9" x 5" (23 cm x 13 cm)	2	350°F/175°C	30-35 min
Dinner Rolls	Single Pan	3	350°F/175°C	10-15 min
	Multiple Pans	1, 3	350°F/175°C	12-15 min
Homemade Pizza				
	Single	3	400°F/205°C	15 min
	Multiple	2, 4	400°F/205°C	15-20 min

CONVECTION QUICK BREADS BAKING CHART

Set Cooking Selections to: TRUE CONVECTION


FOOD	SIZE OF BAKING DISH	RACK POSITION	PREHEATED OVEN TEMPERATURE	APPROXIMATE COOKING TIME
Yeast Breads				
Muffins	Single Pan	3	375°F/190°C	18-25 min
	Multiple Pans	1, 3, 5		18-25 min
Biscuits	Single Sheet	3	425°F/220°C	8 min
	Multiple Sheets	1, 3, 5		10 min
Fruit & Nut Loaves	Loaf Pan 8" x 4" (21 cm x 12 cm)	2	325°F/160°C	45-60 min

CONVECTION DESSERT BAKING CHART

Set Cooking Selections to: TRUE CONVECTION

FOOD	SIZE OF BAKING DISH	RACK POSITION	PREHEATED OVEN TEMPERATURE	APPROXIMATE COOKING TIME
Cookies				
Dropped	Single Sheet	3	350°F/175°C	8-10 min
	Multiple Sheets	1, 3, 5	350°F/175°C	10-12 min
Rolled	Single Sheet	3	375°F/190°C	8-10 min
	Multiple Sheets	1, 3, 5	375°F/190°C	10-12 min
Brownies Loaves	Square Pan 8" - 9" (20 cm - 23 cm)	2	325°F/160°C	35 min
Cakes				
	Round or Square Pan 8" - 9" (20 cm - 23 cm)			
	Single Pan	2	325°F/160°C	30-35 min
	Multiple Pans	2, 4	325°F/160°C	30-35 min
	Rectangular Pan 9" x 13" (23 cm x 33 cm)	2	325°F/160°C	30-35 min
	Bundt Pan 10" (25 cm)	2	325°F/160°C	40-45 min
	Cupcakes	2	325°F/160°C	20-25 min
	Loaf Pan 9" x 5" (23 cm x 13 cm)	2	325°F/160°C	50-60 min
	Angel Food or Spring Form Pan	2	325°F/160°C	35-40 min
Pies				
With Filling	Single 9" (23 cm)	3	375°F/190°C	50-55 min
	Multiple 9" (23 cm)	1, 3, 5	375°F/190°C	55-60 min
Without Filling	Single 9" (23 cm)	3	375°F/190°C	8-10 min
	Multiple 9" (23 cm)	1, 3, 5	375°F/190°C	8-10 min

MODELS 1954 & 1955 NORTHSTAR WIRING DIAGRAM



CLEANING GUIDE

Part	What To Use	How To Clean
Control Knobs	<ul style="list-style-type: none"> • Soft sponge • Warm, soapy water 	<ul style="list-style-type: none"> • Turn knobs to OFF and pull straight off control panel. • Wash, rinse and dry thoroughly. Do not soak. • Replace knobs. Make sure all knobs point to OFF. <p><i>Do Not Use steel wool or abrasive cleaners. They will damage the finish.</i></p>
Exterior Non-Colored Surfaces	<ul style="list-style-type: none"> • Soft sponge • Warm, soapy water • VIM, Flitz or Soft Scrub cleaners 	<ul style="list-style-type: none"> • Wash, rinse and dry thoroughly. • Use non-abrasive, plastic scrubbing pad on heavily soiled areas. • Follow directions on the container. • Do not use abrasive or harsh cleaners.
Glass Cook Tops <i>also see page 9</i>	<ul style="list-style-type: none"> • Soft cloth with warm, soapy water • Vim or Glass Stove Top Cleaner • Corning Cleaner-Conditioner • Dry Baking Soda 	<ul style="list-style-type: none"> • Follow directions on container. • Do not use abrasive or harsh cleaners. • Apply to soiled areas dry with soft cloth.
Porcelain-Enamel Gas Grates	<ul style="list-style-type: none"> • Non-abrasive, plastic scrubbing pad • Warm, soapy water • Wax with Turtle Wax 	<ul style="list-style-type: none"> • Wipe off excess spills. • Wash, rinse and dry thoroughly.
Broiler Pan & Grid <i>(Clean after each use)</i>	<ul style="list-style-type: none"> • Steel-wool pad • Warm, soapy water <i>OR</i> • Self-cleaning cycle 	<ul style="list-style-type: none"> • Wash, rinse and dry thoroughly <i>OR</i> • Leave in oven during self-cleaning cycle.
Oven Racks	<ul style="list-style-type: none"> • Steel-wool pad • Warm, soapy water <i>OR</i> • Self-cleaning cycle 	<ul style="list-style-type: none"> • Wash, rinse and dry thoroughly • Remove from oven during self-cleaning cycle.
Chrome Trim	<ul style="list-style-type: none"> • Maas cleaner, follow directions on tube • Tarnite metal polish (follow directions on can) 	<p><i>NOTE: Racks will discolor and become harder to slide if left in oven during self cleaning cycle. Apply a small amount of vegetable oil to the side rungs to aid sliding.</i></p>
Stainless Steel	<ul style="list-style-type: none"> • Stainless Steel Cleaner and Polish <i>OR</i> • Windex & Papertowel 	<ul style="list-style-type: none"> • Before cleaning make sure drawer is cool • Wash with hot soapy water • Rinse & dry, then use cleaner or windex. • Rub cleaner in direction of the grain.
How Can I Clean Stains Off Painted Enamel?	<ul style="list-style-type: none"> • Soft sponge • Warm, soapy water <i>OR</i> • Windex 	<ul style="list-style-type: none"> • Wash, rinse and dry thoroughly. • Follow directions on the container.
Pancake Griddle <i>(Option)</i>	<ul style="list-style-type: none"> • Plastic scouring pad with soap & water 	<ul style="list-style-type: none"> • Soak then wash in hot soapy water.

STAINS TO COOKTOP:

Acid (tomato, cherries, rhubarb, citrus, milk and vinegar) will permanently stain cooktop and trim if not wiped up immediately.

SERVICING RANGE UNDER COOK TOP

(Servicing should be done by a person knowledgeable in appliance service.) Disconnect power to range. Open oven door and remove it. See removal instructions on page 16. With a Philips Driver, undo the 2 screws holding the top down. Pull top forward about 2" then lift front up about 10". Raise the service stays on each side to hold top up.

RANGE TROUBLESHOOTING

This section is designed to help you save the cost of a service call. However, you may still need assistance or service. When calling for service, you will need to provide a complete description of the problem, your appliance's complete model and serial numbers and the purchase or installation date (see Warranty). This information is needed to properly identify parts needed.

Before Calling For Service...PHONE OUR HELP LINE AT: 1-800-295-8498

If your range should fail to operate, review the following list before calling for service.

Note: Most electrical clock malfunctions can be corrected by turning the power off to the range for about 15 seconds. (Clock and Control will reset itself).

Problem	Check...	What To Do
Nothing will operate	<ul style="list-style-type: none"> • Is the power cord plugged into a live circuit with proper voltage? • Has a household fuse blown or a circuit breaker tripped? 	<ul style="list-style-type: none"> • Plug the power cord into a live circuit with proper voltage. • Replace household fuse or reset circuit breaker.
The oven will not operate	<ul style="list-style-type: none"> • Has the clock been set? • Have the electronic controls been set correctly? • Has a delayed start time been programmed? 	<ul style="list-style-type: none"> • Refer to instructions for setting the electronic controls starting on page 15. • Wait for the start time to be reached.
The electric surface elements will not operate	<ul style="list-style-type: none"> • Has a household fuse blown or a circuit breaker tripped? • Are the control knobs set correctly? • Is a control knob sticking or broken? 	<ul style="list-style-type: none"> • Replace household fuse or reset circuit breaker. • Push control knobs in before turning to a setting. • See LUBRICATION on page 16.
Cooktop control knobs will not turn	<ul style="list-style-type: none"> • Are you pushing in before turning? • See LUBRICATION page 16. 	<ul style="list-style-type: none"> • Push control knobs in before turning to a setting. Call factory for help.
The self-cleaning cycle will not operate	<ul style="list-style-type: none"> • Does the range clock show the correct time of day? • Has a delayed start time been programmed? 	<ul style="list-style-type: none"> • Reset clock to show the correct time of day (see page 14). • Wait for the start time to be reached or reset for immediate start.
Control is "locked up" (meaning no buttons will function)	<ul style="list-style-type: none"> • There has been a power interruption. 	<ul style="list-style-type: none"> • Reset the main power breaker to the range.
Cooking results are not what you expected	<ul style="list-style-type: none"> • Is the range level? • Is the oven preheated before baking? • Has the recipe been tested or is it from a reliable source? • Is the pan used the type or size recommended in a reliable cookbook? • Is there proper air circulation around the pan when baking? • Does cooking utensil fit the surface burner being used? • Have you preheated oven for 15 minutes? 	<ul style="list-style-type: none"> • Level range (see Installation instructions page 6). • Preheat oven when called for in recipe. • Use only tested recipes from a reliable source. • Refer to a reliable cookbook for recommended pan type and size. • Allow 1" to 2" (3.5-5 cm) of air space on all sides of pan. • Pan should be the same size or slightly larger than surface element being used.

GAS TROUBLESHOOTING

Problem	Check...	What To Do
Ignitor doesn't spark when knobs are turned to light.	Dirt on ignitor, defective spark module or valve switch.	Clean ignitors and area between ignitor and burner. Replace module or valve switch.
Burners spark but one does not light.	Check burner, cap, ignitor and orifice for dirt.	Clean dirt from burner, cap or orifice.
Spark occurs at ignitor when all control knobs are off.	Module. Water has been spilled on control panel.	Replace module. Unplug range and let control panel dry overnight.

Proper grounding and polarity are necessary for correct operation of the electric ignition system on model 1956. If the wall receptacle does not provide correct polarity, the ignitor will become grounded and click occasionally, even after the burner is ignited. A qualified electrician should check the wall receptacle for correct polarity and grounding. This sparking condition will also occur if there is a breeze across the burners or when on low. **Warning: Do not touch ignitor when it is sparking.**

**FOR WARRANTY SERVICE
OUR FACTORY HELP LINE NUMBER IS:
1-800-295-8498**

WARRANTY

Your **NorthStar Range** is warranted by **Elmira Stove Works** to be free from defects in material and workmanship for a period of one year from the date of purchase. Elements, burners and smooth tops are warranted for five years.

Elmira Stove Works warrants to replace any parts free of charge which become defective during the period of this warranty. It also warrants to provide fair service labor rates to install the warranted parts during the first year. Glass, light bulbs, enamel, and chrome plating are not covered by the warranty. Warranty is subject to the terms outlined below.

Terms and Conditions

This warranty applies only for residential use in the country of purchase. The range must be properly installed according to this manual and to local building and safety codes. Abuse, accident, alteration or misuse will void this warranty.

Neither **Elmira Stove Works** nor the dealer is liable for any damages or claims resulting from failure of the range or from service delays beyond their control.

Parts repaired or replaced through this warranty are warranted for the balance of the original warranty period.

This warranty does not cover any cost of making the appliance readily available for service, and does not cover labor performed at overtime or premium rates.

Purchase Date: _____ Store: _____

Store Address: _____

Range Model _____

Serial Number _____

Elmira Stove Works
285 Union Street, Elmira, ON Canada N3B 3P1
Tel: 519 669-1281 Fax: 519 669-1774
E-mail: info@elmirastoveworks.com
www.elmirastoveworks.com